



19706 77th Avenue East, Bradenton, FL 34202, U.S.A.
(941) 322-9739, skeeta@skeeta.com, www.skeeta.biz, CAGE: 3E1W4

QUEEN BEDNET (PN131-200)

ASSEMBLY SEQUENCE:



[Queen Bednet packaged in pouch]



1. Remove the poles and reverse the pouch inside out to remove the Queen Bednet.



2. Lay the Queen Bednet flat, square on the ground with the zippers facing up and open, and the pouch on the inside.



3. Connect (2) 60" & (2) 80" Horizontal poles together using corner angles and position rectangular frame into lower inside corners of the Queen Bednet.



4. Connect (1) 60" horizontal pole & (2) 60" vertical poles together using corner angles positioned into upper corners of Queen Bednet, with inverted-U frame poles in the corner angles of lower rectangular frame.



5. Repeat step 4 on other end of the lower rectangular frame, then connect (2) 80" horizontal poles to the top corner angles.



6. Queen Bednet functions on queen-size bed frame, with zippered door flaps that wrap around vertical poles to stay open.



REPACKAGING SEQUENCE:

1. Disconnect horizontal poles sections from corner angles of upper rectangular frame, and remove.
2. Disconnect vertical poles sections from corner angles of lower rectangular frame, and remove.
3. Remove the lower rectangular frame and disconnect all 80" pole sections from angle connectors while leaving angle connectors attached to each end of 60" pole sections.
4. Reverse the Queen Bednet inside out, zip closed, and lay pouch flat on ground with 80" pole sections on top at other end.
5. Roll-up Queen Bednet around 80" poles and position above pouch, then reverse pouch around, while stuffing Queen Bednet inside. Add 60" poles on top, and zip the pouch closed.