



19706 77th Avenue East, Bradenton, FL 34202, U.S.A.
(941) 322-9739, skeeta@skeeta.com, www.skeeta.biz, CAGE: 3E1W4

UNIVERSAL BEDNET (PN131-100)

ASSEMBLY SEQUENCE:



[Universal Bednet packaged in pouch]



1. Remove the poles and reverse the pouch inside out to remove the Universal Bednet.



2. Lay the Universal Bednet flat, square on the ground with the zippers facing up and open, and the pouch on the inside.



3. Connect (2) 60" & (2) 80" Horizontal poles together using corner angles and position rectangular frame into lower inside corners of the Universal Bednet.



4. Connect (1) 60" horizontal pole & (2) 80" vertical poles together using corner angles positioned into upper corners of Universal Bednet, with inverted-U frame poles in the corner angles of lower rectangular frame.



5. Repeat step 4 on other end of the lower rectangular frame, then connect (2) 80" horizontal poles to the top corner angles.



6. Universal Bednet functions in queen-size and king-size orientations, with zippered door flaps that wrap around vertical poles to stay open.



REPACKAGING SEQUENCE:

1. Disconnect horizontal poles sections from corner angles of upper rectangular frame, and remove.
2. Disconnect vertical poles sections from corner angles of lower rectangular frame, and remove.
3. Remove the lower rectangular frame and disconnect all 80" pole sections from angle connectors while leaving angle connectors attached to each end of 60" pole sections.
4. Reverse the Universal Bednet inside out, zip closed, and lay pouch flat on ground with 80" pole sections on top at other end.
5. Roll-up Universal Bednet around 80" poles and position above pouch, then reverse pouch around, while stuffing Universal Bednet inside. Add 60" poles on top, and zip the pouch closed.